



AQD745 Deck Mount Time Flow Tap Installation & Operating Instructions



Congratulations on purchasing this quality water efficient tap set.

Our Products are manufactured to the highest standards under strict quality control procedures, and come with our exclusive on-site parts and labour warranty.

This Commercial tapware is factory assembled and designed for easy installation and maintenance.

Standards / Compliances: Instal Acqualine tapware with confidence, our products are tested to AS/NZS3718, AS4020 and AS/NZS6400. This tapset can only be used on mains pressure systems and is Wels 3 Star rated.

Please follow these instructions:

1. Screw in the fixing bolt/s and tighten with a screwdriver.
2. Place the tap unit in the pre-punched hole (**22mm cutout**) in the sink or basin, after connecting a flexible hose (not supplied).
3. From underneath the sink or basin, fix rubber seal, fixing plate and fixing nut/s in the respective order.
4. Tighten the fixing nut/s with socket set or tube spanner to clamp the mixer onto the sink/ basin. Ensure the tapset is firmly attached to the sink or basin.
5. Flush the pipelines to clear any foreign matter. Connect the mixer to the water supply line by connecting the flexible connector to the isolating stop valve.
6. After full connection to the water supply, remove aerator before initial water test.

NOTE: Failure to comply with the following will void all warranty:

- Approved operating temperature is not to exceed 60°C (Installing a **AQ6000 Thermostatic Mixer Valve** is recommended)
- Minimum Operating Pressure 150KPa*.
- If the incoming water pressure exceeds 500KPa, an approved pressure limiting valve **MUST** be fitted.
- This warranty is extended to the original purchaser only and is not transferable. (Retain your invoice for proof of purchase).
- All taps should be installed with isolating stop valves by a registered plumber.
- Use only mild detergents and water to clean the surface of your tapset (ie. No abrasive cleaners)
- All new connections must be flushed thoroughly before use.

***Optimum Operating Pressure is between 250 - 350Kpa**

IMPORTANT NOTE:

We do not recommend dismantling the internal parts of the tap set. The tapsets are individually factory assembled and tested to give maximum performance.

**For all service, warranty or spare parts
requirements, please call**

03 9368 2300